

FABRICATION AND INSTALLATION INSTRUCTIONS FOR GENERIC SUPPORT MULLIONS

UL File No.
R25410




These installation instructions apply to the fabrication and construction of generic support mullions. Support mullions are necessary whenever fire dampers are installed into an opening that is larger than the largest UL rated size for that damper. The mullions allow construction of a fire barrier that is larger than the maximum U.L. available size. The opening must not exceed 120" high, but can be any width provided a vertical support mullion is used at a maximum of every 120". To properly use support mullions they must be fabricated and installed according to these instructions. This generic support mullion is permitted by UL to only be used in static systems. A static system is one in which the fan shuts down in the event of a fire or smoke alarm.

Application

Generic steel mullions can be used to separate vertically mounted galvanized steel fire dampers in wall openings larger than the UL permitted multiple damper assembly size. Mullions a 1-1/2 hour fire resistance rating. Maximum mullion span is 120" plus expansion allowance when used either horizontally or vertically. Sleeves are to be around each damper assembly. Mullions are not intended to be in the airstream, (i.e. exposed to flow) or to be a part of the ductwork.


Wall Opening

Steel mullions are intended for use in a concrete block or solid concrete wall. Hollow concrete blocks are to be filled with concrete (minimum 3500 psi) to permit proper mullion anchoring. Wall thickness is to be 7" minimum, 12" maximum.




FABRICATION AND INSTALLATION INSTRUCTIONS FOR SUPPORT MULLIONS

Support mullion assemblies consist of three basic parts: the wall mullion cap, the horizontal to vertical mullion cap and the mullion sections. Determine the number of each piece required to complete the installation.




**Formed Section
End View**



**Cap End Plate
(2 req'd.)**

DETAIL A-A



**Wall Mullion Cap
Assembled View**

Table 1

Dimensional Information

Opening Width/Height	D	H
12	11-1/2"	3-1/4"
24	23-1/2"	3-3/8"
36	33-3/8"	3-1/2"
48	47-1/4"	3-5/8"
60	59-1/8"	3-3/4"
72	71"	3-7/8"
84	82-7/8"	4"
96	94-3/4"	4-1/8"
108	106-3/4"	4-1/4"
120	118-3/4"	4-3/8"

E = Wall Thickness - 1/2"
F = Wall Thickness + 1/4"

Fabrication of Wall Mullion Caps (Fig. A-A)

Wall mullion caps must be constructed from 12 ga. steel with a minimum yield strength of 42,000 psi.

1. Fabricate the formed section as shown to right.
2. Shear the cap end plate to required dimensions.
3. Weld the cap end plates to the formed section with 1/8" fillet welds completely around the top edges of the formed section.
4. Drill and countersink 8 holes (4 on each side for 1/4" - 20 flat head machine screws.

Fabrication of Mullion Sections (Fig. B-B)



Mullions must be constructed from 16 ga. steel with a minimum yield strength of 42,000 psi.

Important: The "D" dimension shown has been calculated to include the necessary clearances required for thermal expansion in the mullions. The values can be found using the wall opening dimensions and tables on this page.

1. Form two identical pieces of mullion section as shown.
2. Connect the two mullion sections together. Use 3/16" steel blind rivets or 3/4" long intermittent welds 12" on center and a 6" maximum from both ends.

Important: Both sides of the mullion piece should be fastened using the method described above.

DETAIL B-B



3/16" blind rivet (std.) or 3/4" long intermittent welds 12" on center, 6" max from both ends, both sides of assy.
3/16" typ. rivet location




FABRICATION AND INSTALLATION INSTRUCTIONS

FOR SUPPORT MULLIONS

Fabrication of Horizontal to Vertical Mullion Caps (Fig. C-C)

Horizontal to vertical mullion caps must be constructed from 12 ga. steel with a minimum yield strength of 42,000 psi. Important: The H, E and F dimensions shown have been calculated to provide the correct performance. The values can be found by using the wall opening dimensions and the tables on page 2.

1. Form the horizontal mullion channel as shown.
2. Drill 12, $\frac{3}{16}$ " dia. holes into the horizontal mullion channel using the dimensions shown.
3. Form the center channel as shown.
NOTE: If the center channel is to be made from two pieces, weld them together with an $\frac{1}{8}$ " fillet weld.
4. Shear the end plates to the dimensions required.
5. Weld the end plates to the center channel with $\frac{1}{8}$ " fillet welds completely around the top edges of the center section.



DETAIL C-C